


Replacement Parts
for
Prime Mover SMX45 Walkie





800-462-2370

www.SuperStoresService.com

Prime Mover SMX45 Walkie

Prime Mover SMX45 Walkie

800-462-2370
www.SuperStoresService.com



Contents

Wheels

[Quick Wheel Lookup](#) 4

Electrical

[Battery Charger, Battery Connector, Motor Controllers](#) 6

Drive Unit

[Drive Motor Parts, Brake Assembly](#) 8

Control Handle

[Arm, Throttle Assembly](#) 10

Hydraulic System

[Hydraulic System](#) 12

Frame and Undercarriage

[Frame and Undercarriage](#) 14

Quick Wheel Lookup

Quick Wheel Lookup

[back to Contents](#)

OEM #	Wheel OD Description	Tread Width in / mm	Hub Width mm	Hub ID mm	Bearing ID mm	Bearing Material/Color			
PR 312636-000	Load Wheel, Poly 95A			3.25 / 82.5	4.00 / 101.5	4.50 / 114	2.047 / 52	0.984 / 25	Dururun Poly 95A, Scotch
PR 312636-000-A	Load Wheel Assembly, Poly 95A			3.25 / 82.5	4.00 / 101.5	4.50 / 114	2.047 / 52	0.984 / 25	BS 6205 2RS Dururun Poly 95A, Scotch
PR 312636-000-XL	Load Wheel, Poly 97A			3.25 / 82.5	4.00 / 101.5	4.50 / 114	2.047 / 52	0.984 / 25	XL Poly 97A, White
PR 312636-000-XL-A	Load Wheel Assembly, Poly 97A			3.25 / 82.5	4.00 / 101.5	4.50 / 114	2.047 / 52	0.984 / 25	BS 6205 2RS XL Poly 97A, White
GWK-SMX45-LW	Load Wheel Kit, Includes (2) Load Wheels, Bearings, Axles & Fasteners			3.25 / 82.5	4.00 / 101.5	4.50 / 114	2.047 / 52	0.984 / 25	BS 6205 2RS Dururun Poly 95A, Scotch
GWK-SMX45-LW-XL	Load Wheel Kit, Includes (2) Load Wheels, Bearings, Axles & Fasteners			3.25 / 82.5	4.00 / 101.5	4.50 / 114	2.047 / 52	0.984 / 25	BS 6205 2RS XL Poly 97A, White
PR 312678-000	Drive Tire, Rubber Smooth Flat			10.00 / 254	4.00 / 101.5	5.00 / 127	6.50 / 165		Rubber, Black
PR 313054-001	Drive Tire Assembly, Rubber Smooth Flat, Includes Hub			10.00 / 254	4.00 / 101.5	5.00 / 127	6.50 / 165		Rubber, Black
PR 312678-002	Drive Tire, Poly Smooth Flat			10.00 / 254	4.00 / 101.5	5.00 / 127	6.50 / 165		Poly 87A, Red
PR 313054-003	Drive Tire Assembly, Poly Smooth Flat, Includes Hub			10.00 / 254	4.00 / 101.5	5.00 / 127	6.50 / 165		Poly 87A, Red
PR 312895-000	Hub								
PR 313945-000	Dururun 95A Poly Caster Wheel Assembly			2.50 / 63.5	2.00 / 51	2.375 / 60	1.37 / 35	0.50 / 12.7	BS 1621 2RS Dururun Poly 95A, Scotch
PR 313945-000-XL	XL 97A Poly Caster Wheel Assembly			2.50 / 63.5	2.00 / 51	2.375 / 60	1.37 / 35	0.50 / 12.7	BS 1621 2RS XL Poly 97A, White
PR 313729-001	Caster Assembly Complete								

GWK-SMX45-LW

Load Wheel Assembly



GWK-SMX45-LW-XL

Load Wheel Assembly



PR 312636-000

Poly Load Wheel, 95A



PR 313054-001

Drive Tire Assembly, Rubber Smooth Flat, Includes Hub



PR 312678-002

Drive Tire, Poly Smooth Flat



PR 313054-003

Drive Tire Assembly, Poly Smooth Flat, Includes Hub



PR 312636-000-A

Poly Load Wheel Assembly, 95A



PR 312636-000-XL

Poly Load Wheel, 97A



PR 312636-000-XL-A

Poly Load Wheel Assembly, 97A



PR 313945-000

Dururun 95A Poly Caster Wheel Assembly



PR 313945-000-XL

XL 97A Poly Caster Wheel Assembly




PR 313729-001

Caster Assembly Complete



Battery Charger, Battery Connector, Motor Controllers





Battery Charger, Battery Connector, Motor Controllers

[back to Contents](#)

Item	Part No.	Description
1	PR 49854-01	Battery Connector SB175 Gray
	PR 49854-04	Battery Connector SB175 Blue
	PR 49854-08	Battery Connector SB175 Red
2	PR 313151-000	Disconnect Handle, Inc Screws & Nuts
3	PR 305493-000	Master On/Off Switch
4	PR 302016-000	Key Switch, Inc. 2 Keys
5	PR 308030-000	Switch
6	PR 20208-01	Lift Limit Switch
7	PR 312668-001	Controller
8	PR 313066-000	Main Contactor
9	PR 309984-000	Relay
10	PR 301890-003	Circuit Breaker
11	PR 310456-000	Horn
12	PR 314408-000	Main Harness
13	PR 313436-000	Head Harness
14	PR 25275-12	Fuse, 10 Amp
15	PR 313202-000	Fuse, 80 Amp
16	PR 310079-000	Battery Carger 24V

Drive Motor Parts and Brake Assembly




Drive Motor Parts and Brake Assembly

[back to Contents](#)

Item	Part No.	Description
1	PR 312675-000	Drive Unit & Motor Assembly (not shown)
2	PR 313735-000	Drive Axle
3	PR 313736-000	Seal
4	PR 313737-000	Bearing, Drive Axle
5	PR 313778-000	Spacer
6	PR 313757-000	Armature (not shown)
7	PR 313756-000	Seal
8	PR 313755-000	Shim
9	PR 313754-000	Bearing
10	PR 313752-000	Field Coil
11	PR 313768-000	Bearing
12	PR 313763-000	Brush Holder
13	PR 313765-000	Brush
14	PR 313764-000	Spring
15	PR 313762-000	Cover
16	PR 313760-000	Band
17	PR 313738-000	Brake Assembly (not shown)

Control Handle - Arm, Throttle Assembly



Control Handle - Arm, Throttle Assembly

[back to Contents](#)

Item	Part No.	Date/Serial Range	Description
1	PR 312677-000		Handle Stem
2	PR 313067-000		Handle Stem Pin
3	PR 313048-000		Stem Mount
4	PR 312855-001		Return Spring
5	PR 314184-000		Control Card
6	PR 171666		Lift Lower Button
7	PR 171664		Reverse Button
8	PR 167836		Spring
9	PR 313051-000		Thumb Wheel Assembly
10	PR 167840		Spring
11	PR 171655		Horn Switch
12	PR 167847		Horn Button, Right
13	PR 167848		Horn Button Left
14	PR 313052-000		Handle
15	PR 313063-000		Bushing
16	PR 313053-000		Control Handle Assembly (not shown)

Hydraulic System




Hydraulic System

[back to Contents](#)

Item	Part No.	Date/Serial Range	Description
1	PR 312679-000		Lift Pump & Motor Assembly (not shown)
2	PR 313621-000		Pump Motor Assembly
3	PR 313694-000		Brush & Spring Kit
4	PR 313695-000		Bearing
5	PR 313615-000		Pump Kit (not shown)
6	PR 308203-000		Solenoid
7	PR 300131-000		Release Valve Kit (not shown)
8	PR 313557-000		Lift Cylinder Assembly
9	PR 23084-00		Seal Kit

Frame and Undercarriage



Frame and Undercarriage

[back to Contents](#)

Item	Part No.	Description
1	PR 312636-000	Poly Load Wheel, 95A Durometer
	PR 312636-000-A	Poly Load Wheel Assembly, 95A Durometer, Includes Bearings
	PR 312636-000-XL	Poly Load Wheel, 97A Durometer
	PR 312636-000-XL-A	Poly Load Wheel Assembly, 97A Durometer, Includes Bearings
	GWK-SMX45-LW	Load Wheel Kit, Includes (2)Load Wheels, Bearings, Axles & Fasteners
	GWK-SMX45-LW-XL	Load Wheel Kit, Includes (2)Load Wheels, Bearings, Axles & Fasteners
2	PR 49910-05	Bearing
3	PR 4312650-000	Load Wheel Axle
	PR 313185-000	Load Wheel Axle, Freezer/Corrosion Resistant
4	PR 301740-003	Set Screw
5	PR 312638-000	Wheel Fork, Includes Bushings
6	PR 312672-000	Bushing
7	PR 312651-000	Pivot Pin
	PR 312651-003	Pivot Pin, Freezer/Corrosion Resistant
8	PR 311390-000	Grease Fitting
9	PR 312651-002	Pin
	PR 312651-005	Pin, Freezer/Corrosion Resistant
10	PR 312651-001	Pin
	PR 312651-004	Pin, Freezer/Corrosion Resistant
11	PR 312666-000	Pin, Weldment
	PR 312666-001	Pin, Weldment, Freezer/Corrosion Resistant
12	PR 313945-000	Poly Caster Wheel, Includes Bearings, 95A Durometer
	PR 313945-000-XL	Poly Caster Wheel, Includes Bearings, 97A Durometer
13	PR 313958-000	Bearing
14	PR 313948-000	Axle Bolt
15	PR 313947-000	Nut
16	PR 313729-001	Caster Assembly, Includes Items 12-15



800-462-2370

www.SuperStoresService.com