


Replacement Parts for Prime Mover SMX45 Walkie





Quick Wheel Lookup	4
Electrical System Components Battery Connector, Motor Controllers	6
Drive Unit Drive Motor Parts, Brake Assembly	8
Control Handle Arm, Throttle Assembly	10
Hydraulic System	12
Frame and Undercarriage	14

Quick Wheel Lookup

Quick Wheel Lookup

OEM #	Description	Wheel OD in/mm	Tread Width in/mm	Hub Width in/mm	Hub ID in/mm	Bearing ID in/mm	Bearing #	Material/Color
PR 312651-001	Load Wheel, Poly 95A	3.25 / 82.5	4.00 / 101.5	4.50 / 114	2.047 / 52	0.984 / 25	BS62052RS	Scotch, 95A
PR 312636-000-A	Load Wheel Assembly, Poly 95A	3.25 / 82.5	4.00 / 101.5	4.50 / 114	2.047 / 52	0.984 / 25	BS62052RS	Scotch, 95A
PR 49910-05	Bearing (2RS)							
PR 312678-000	Drive Tire, Smooth Flat Rubber	10.00 / 254	4.00 / 101.5	5.00 / 127	6.5 / 165.1			Rubber
PR 312678-002	Drive Tire, Smooth Flat Poly 95A	10.00 / 254	4.00 / 101.5	5.00 / 127	6.5 / 165.1			Poly, 95A
PR 312895-000	Drive Tire Hub							
PR 313046-000	Lug Nut							
PR 313945-000	Caster Wheel Assembly	2.50 / 63.5	2.375 / 60.25	2.375 / 60.25	1.181 / 35	0.50 / 12.70	BS16212RS	Poly, 95A

PR 312651-001
Load wheel , Poly, 95A



PR 49910-05
Bearing



PR 312678-002
Drive tire, Poly 95A



PR 313945-000
Caster wheel assembly



PR 312636-000-A
Load Wheel assembly Poly 95A
includes bearings, washers






PR 312678-000
Drive tire, smooth flat rubber



PR 313046-000
Lug nut





Electrical - Battery Connector, Motor Controllers



Electrical - Battery Connector, Motor Controllers

Item	Part No.	Description
1	PR 49854-01	Battery Connector SB175 Gray
	PR 49854-04	Battery Connector SB175 Blue
	PR 49854-08	Battery Connector SB175 Red
2	PR 313151-000	Disconnect Handle, Inc Screws & Nuts
3	PR 305493-000	Master On/Off Switch
4	PR 302016-000	Key Switch, Inc. 2 Keys
5	PR 308030-000	Switch
6	PR 20208-01	Lift Limit Switch
7	PR 312668-001	Controller
8	PR 313066-000	Main Contactor
9	PR 309984-000	Relay
10	PR 301890-003	Circuit Breaker
11	PR 310456-000	Horn
12	PR 314408-000	Main Harness
13	PR 313436-000	Head Harness
14	PR 25275-12	Fuse, 10 Amp
15	PR 313202-000	Fuse, 80 Amp


Drive Unit - Drive Motor Parts, & Brake



Drive Unit - Drive Motor Parts, & Brake

Item	Part No.	Description
1	PR 312675-000	Drive Unit & Motor Assembly (not shown)
2	PR 313735-000	Drive Axle
3	PR 313736-000	Seal
4	PR 313737-000	Bearing, Drive Axle
5	PR 313778-000	Spacer
6	PR 313757-000	Armature (not shown)
7	PR 313756-000	Seal
8	PR 313755-000	Shim
9	PR 313754-000	Bearing
10	PR 313752-000	Field Coil
11	PR 313768-000	Bearing
12	PR 313763-000	Brush Holder
13	PR 313765-000	Brush
14	PR 313764-000	Spring
15	PR 313762-000	Cover
16	PR 313760-000	Band
17	PR 313738-000	Brake Assembly (not shown)

Control Handle - Arm, Throttle Assembly



Control Handle - Arm, Throttle Assembly

Item	Part No.	Description
1	PR 312677-000	Handle Stem
2	PR 313067-000	Handle Stem Pin
3	PR 313048-000	Stem Mount
4	PR 312855-001	Return Spring
5	PR 314184-000	Control Card
6	PR 171666	Lift Lower Button
7	PR 171664	Reverse Button
8	PR 167836	Spring
9	PR 313051-000	Thumb Wheel Assembly
10	PR 167840	Spring
11	PR 171655	Horn Switch
12	PR 167847	Horn Button, Right
13	PR 167848	Horn Button Left
14	PR 313052-000	Handle
15	PR 313063-000	Bushing
16	PR 313053-000	Control Handle Assembly (not shown)


Hydraulic System



Hydraulic System

Item	Part No.	Description
1	PR 312679-000	Lift Pump & Motor Assembly (not shown)
2	PR 313621-000	Pump Motor Assembly
3	PR 313694-000	Brush & Spring Kit
4	PR 313695-000	Bearing
5	PR 313615-000	Pump Kit (not shown)
6	PR 308203-000	Solenoid
7	PR 300131-000	Release Valve Kit (not shown)
8	PR 313557-000	Lift Cylinder Assembly
9	PR 23084-00	Seal Kit

Frame and Undercarriage



Frame and Undercarriage

Item	Part No.	Description
1	PR 312636-000	Load wheel, Poly 95A
2	PR 49910-05	Bearing
3	PR 4312650-000 PR 313185-000	Load Wheel Axle Load Wheel Axle, Cold Storage
4	PR 301740-003	Set Screw
5	PR 312638-000	Wheel Fork
6	PR 312672-000	Bushing
7	PR 312651-000 PR 312651-003	Pivot Pin Pivot Pin, Cold Storage
8	PR 311390-000	Grease Fitting
9	PR 312651-002 PR 312651-005	Pin Pin, Cold Storage
10	PR 312651-001 PR 312651-004	Pin Pin, Cold Storage
11	PR 312666-000 PR 312666-001	Pin Pin, Cold Storage
12	PR 313945-000	Caster Wheel
13	PR 313958-000	Bearing
14	PR 313948-000	Axle Screw
15	PR 313947-000	Nut
16	PR 313729-001	Caster Assembly



800-462-2370

Fax 800-366-5939

www.SuperStoresService.com