


Jet A, L and J Hydraulic Unit



Jet A, L and J Hydraulic Unit

Item	Part No.	Description
1	PT2748A-001	Handle Assembly (Includes Items 1-15)
2	PT2748A-002	Handle Cap
3	PT2748A-003	Control Lever
4	PT2748A-004	Screw
5	PT2748A-005	Roll Pin
6	PT2748A-006	Bushing
7	PT2748A-007	Spring Pin
8	PT2748A-008	Bushing
9	PT2748A-009	Roller
10	PT2748A-010	Roller Pin
11	PT2748A-011	Release Rod
12	PT2748A-012	Chain Joint
13	PT2748A-013	Chain
14	PT2748A-014	Anchor Bolt
15	PT2748A-015	V-Nut
16	PT2748A-032	Snap Ring
17	PT2748A-033	Pump Piston
18	PT2748A-034	Spring Cap
19	PT2748A-035	Spring
20	A PT2748A-020	Dust Seal
21	A PT2748A-021	Back-Up Ring
22	A PT2748A-022	O-Ring
	A PT2748J-020	U-Cup
23	PT2748A-024	Ball
24	PT2748A-025	Ram Piston, Before Serial #704xxx (Located On Pump)
	PT2748A-025A	Ram Piston, After Serial #704xxx (Located On Pump)
	PT2748J-025	Ram Piston (J Model)
25	A PT2748A-016	Dust Seal
26	A PT2748A-017	O-Ring
	A PT2748J-016	U-Cup
27	A PT2748A-018	Back-Up Ring
28	PT2748A-026	Oil Plug
29	A PT2748A-023	O-Ring
30	PT2748A-109	Pump Housing, New (Replaces PT2748-109)
	HU JT PT2748A/L	Rebuilt Hydraulic Unit - Exchange
31	PT2748A-027	Pressure Adjustment Screw
32	A PT2748A-028	O-Ring
33	PT2748A-029	Release Screw
34	PT2748A-030	Spring
35	PT2748A-031	Steel Ball
36	PT2748A-036	Release Plug

Item	Part No.	Description
37	PT2748A-037	Washer
38	PT2748A-038	Outer Spring
	PT2748A-038A	Inner Spring (Not Shown)
39	PT2748A-040	Ball
40	PT2748A-039	Valve Housing
41	PT2748A-040A	Steel Ball
42	PT2748A-041	Spring Pin
43	PT2748A-042	Spring Pin
44	PT2748A-044	Spring Pin
45	PT2748A-043	Snap Ring
46	PT2748A-048	Handle Pin
47	PT2748A-049	Washer
48	PT2748A-050	Thrust Bearing
49	PT2748A-051	Spring
50	A PT2748A-019	O-Ring
51	PT2748A-052	Release Pin
52	PT2748A-053	Actuator
53	PT2748A-046	Wheel Shaft
54	PT2748L-103	Steer Wheel Assembly, Model L, Black Ultra-Poly W/ Bearings
	GWK-JETL-CK	Complete Wheel Kit, Model L, (2) Ultra-Poly Load Roller Assemblies, (2) Poly Steer Wheel Assemblies, W/ Bearings, Axles & Fasteners
	PT2748A-060-HD	Steer Wheel Assembly, Model A or J, Red Ultra-Poly On Aluminum Hub W/ Bearings
	PT2748A-060-ST	Steer Wheel Assembly, Model A or J, Black Ultra-Poly On Nylon W/ Bearings
	GWK-JETA-CK	Complete Wheel Kit, Model A, (2) Ultra-Poly Load Roller Assemblies, (2) Poly Steer Wheel Assemblies, W/ Bearings, Axles & Fasteners
	GWK-JETJ-CK	Complete Wheel Kit, Model J, (2) Ultra-Poly Load Roller Assemblies, (2) Poly Steer Wheel Assemblies, W/ Bearings, Axles & Fasteners
55	PT2748A-062	Washer
56	PT2748A-063	Lock Washer
57	PT2748A-064	Bolt
58	PT2748A-061	Hub Cap (OEM Wheel Only)
59	PT2748A-065	Lock Washer (OEM Wheel Only)
60	PT2748A-066	Screw (OEM Wheel Only)
61	PT2748A-055	Traverse
62	PT2748A-103-BS-1	Steer Wheel Ball Bearing, 25mm ID
63	PT2748A-103-BS-2	Steer Wheel Ball Bearing, 25mm ID
64	PT2748A-054	Roll Pin
KITS	A PT2748A-101	Complete Seal Kit, Model A,L & J